

SafeAll Driveline Pro

Installation Guide



Thanks for choosing **SafeAll's Driveline Pro**. We've designed this toolkit to make it easier to remove or disconnect a commercial vehicle's driveshaft for towing or service. Installation instructions are shown on reverse. For more information, visit **SafeAllProducts.com**.

Toolkit includes:

- A. Ratcheting Hanger Bar
- B. Spring Clip Ratcheting Rope Assembly
- C. Hook-End Ratcheting Rope Assembly



Installation instructions



Insert hanger bar. Wedge the hanger bar between the truck's frame rails, making sure the padded C-brackets are tight against each lip. Close the handle so the spring loaded lock engages.



Remove the driveshaft. Remove the driveshaft, allowing the rope assembly to carry the weight.



Lateral securement. Utilizing the hook-end ratcheting rope assembly, secure the ratchet hook end on a crossmember or frame rail of the truck. Wrap the spliced hook end of the rope between the u-joint and driveshaft – then hook back to itself. Ratchet the rope tight.



Cradle the driveshaft. Cradle the spring clip ratcheting rope assembly around the driveshaft. Ratchet the rope assembly tight to the drive shaft.



Adjust for travel. Using the ratchet, raise or lower the driveshaft into proper position. If offset placement is necessary, tie both spring clips into the same steel loop and adjust the height.

© 2022 SafeAll Products



